



Appliances

- ⑥ Replace old appliances with Energy Star® certified appliances.
- ⑥ Vacuum under or behind refrigerator to keep coils free of dirt, dust and pet hair.
- ⑥ Unplug any extra refrigerators or freezers. Remember that an empty refrigerator or freezer uses more energy than a full one.
- ⑥ Use "air dry" button or shut off "heated dry" setting on dishwasher.
- ⑥ Do full loads and use cold water in your clothes washer.
- ⑥ Always clean your lint filter after every dryer load.
- ⑥ Use a clothesline in warm weather.
- ⑥ Make sure the dryer exhaust vent is not kinked or has too many bends.
- ⑥ Use a microwave instead of your stove for cooking.
- ⑥ Keep range-top coils and reflectors clean.
- ⑥ Cook with lids on pans.
- ⑥ Turn spas down when on vacation.
- ⑥ Turn off computers when not in use.

